

|          |                         |
|----------|-------------------------|
| Section: | Interface/SingleStation |
|----------|-------------------------|

The single station page provides all the informations about a station. The station name and/or serial number is displayed at the top of the page. Some links to the history plots (see section Interface/HistoryPlots), to the data logger itself and to the ping tool follow. Some files of interest are also available: Osiris information file (oif), Osiris log file (olf) and Osiris parameter file (opf). The highest level of details is obtained in verbose mode.

The single station page offers the user to connect to the data logger and also to start the real time monitor. This feature requires a Java virtual machine to be installed on the client PC (that is not necessarily the PC running OMNI).

The tile (see Interface/StationTile) is displayed together with the Osiris error messages (internal stack of the last 10 messages issued by the data logger).

The Osiris information are then grouped by function: health, time, GPS, disk, trigger, channels, FTP, SeedLink.

At the end of the page are listed the events that have a record from the current station.